

# Kit 1205


**TOYOTA Corolla**, 4-dr Sedan, 00-06 (JPN)

**TOYOTA Corolla**, 5-dr Estate, 00-06



**TOYOTA Corolla**, 5-dr Hatchback, 02-04, 05-06

**TOYOTA Corolla Runx**, 5-dr Hatchback, 01-04, 05-06


**TOYOTA Alex**, 5-dr Hatchback, 01-04, 05-08



**754** Rapid System  
**480R** Rapid Traverse (North America)



**480** Traverse (North America)






754 Rapid System  
480R Rapid Traverse (North America)

480 Traverse (North America)



1






2






754 Rapid System  
480R Rapid Traverse  
(North America)




x4





x4



x4




480 Traverse  
(North America)





x4


**3**



**754** Rapid System



	<b>X</b>
<b>TOYOTA Corolla</b> , 4-dr Sedan, 00-06 (JPN)	<b>32</b>
<b>TOYOTA Corolla</b> , 5-dr Estate, 00-06	<b>32</b>
<b>TOYOTA Corolla</b> , 5-dr Hatchback, 02-04, 05-06	<b>31,5</b>
<b>TOYOTA Corolla Runx</b> , 5-dr Hatchback, 01-04, 05-06	<b>31,5</b>
<b>TOYOTA Allex</b> , 5-dr Hatchback, 01-04, 05-08	<b>31,5</b>



	<b>Y</b>
<b>TOYOTA Corolla</b> , 4-dr Sedan, 00-06 (JPN)	<b>35</b>
<b>TOYOTA Corolla</b> , 5-dr Estate, 00-06	<b>32,5</b>
<b>TOYOTA Corolla</b> , 5-dr Hatchback, 02-04, 05-06	<b>34,5</b>
<b>TOYOTA Corolla Runx</b> , 5-dr Hatchback, 01-04, 05-06	<b>34,5</b>
<b>TOYOTA Allex</b> , 5-dr Hatchback, 01-04, 05-08	<b>34,5</b>

**3**




**480R** Rapid Traverse




**480** Traverse



**(North America)**







	<b>X inch</b>	<b>X mm</b>
<b>TOYOTA Corolla</b> , 4-dr Sedan, 00-06 (JPN)	<b>38 1/4"</b>	<b>971 mm</b>
<b>TOYOTA Corolla</b> , 5-dr Estate, 00-06	<b>38 1/4"</b>	<b>971 mm</b>
<b>TOYOTA Corolla</b> , 5-dr Hatchback, 02-04, 05-06	<b>38"</b>	<b>966 mm</b>
<b>TOYOTA Corolla Runx</b> , 5-dr Hatchback, 01-04, 05-06	<b>38"</b>	<b>966 mm</b>
<b>TOYOTA Allex</b> , 5-dr Hatchback, 01-04, 05-08	<b>38"</b>	<b>966 mm</b>



	<b>Y inch</b>	<b>Y mm</b>
<b>TOYOTA Corolla</b> , 4-dr Sedan, 00-06 (JPN)	<b>39 3/8"</b>	<b>1001 mm</b>
<b>TOYOTA Corolla</b> , 5-dr Estate, 00-06	<b>38 3/8"</b>	<b>976 mm</b>
<b>TOYOTA Corolla</b> , 5-dr Hatchback, 02-04, 05-06	<b>39 1/4"</b>	<b>996 mm</b>
<b>TOYOTA Corolla Runx</b> , 5-dr Hatchback, 01-04, 05-06	<b>39 1/4"</b>	<b>996 mm</b>
<b>TOYOTA Allex</b> , 5-dr Hatchback, 01-04, 05-08	<b>39 1/4"</b>	<b>996 mm</b>

**4**





**5****TOYOTA Corolla, 4-dr Sedan, 00-06 (JPN)****TOYOTA Corolla, 5-dr Estate, 00-06**

# 5



**TOYOTA Corolla**, 5-dr Hatchback, 02-04, 05-06

**TOYOTA Corolla Runx**, 5-dr Hatchback, 01-04, 05-06


**TOYOTA Allex**, 5-dr Hatchback, 01-04, 05-08




6




	X mm	Y mm	X inch	Y inch
<b>TOYOTA Corolla, 4-dr Sedan, 00-06 (JPN)</b>	230 mm	727 mm	9"	28 <sup>5</sup> / <sub>8</sub> "
<b>TOYOTA Corolla, 5-dr Estate, 00-06</b>	240 mm	715 mm	9 <sup>1</sup> / <sub>2</sub> "	28 <sup>1</sup> / <sub>8</sub> "



**TOYOTA Corolla, 4-dr Sedan, 00-02 (JPN)**





**TOYOTA Corolla, 5-dr Estate, 00-06**







6




	X mm	Y mm	X inch	Y inch
<b>TOYOTA Corolla</b> , 5-dr Hatchback, 02-04, 05-06	240 mm	710 mm	9 1/2"	28"
<b>TOYOTA Corolla Runx</b> , 5-dr Hatchback, 01-04, 05-06	240 mm	710 mm	9 1/2"	28"
<b>TOYOTA Allex</b> , 5-dr Hatchback, 01-04, 05-08	240 mm	710 mm	9 1/2"	28"



**TOYOTA Corolla**, 5-dr Hatchback, 02-04, 05-06  
**TOYOTA Corolla Runx**, 5-dr Hatchback, 01-04, 05-06  
**TOYOTA Allex**, 5-dr Hatchback, 01-04, 05-08



7



**GB/US** Tighten alternately  
**D** Die Schrauben abwechselnd anziehen  
**F** Serrer alternativement chaque côté  
**NL** Afwisselend aan de linker- en de rechterkant aandraaien  
**I** Alternare il serraggio delle viti  
**E** Apertar alternativamente  
**PT** Aperte alternadamente  
**S** Dra åt växelvis  
**FIN** Kierrä vuorotellen  
**EST** Pinguldage vaheldumisi  
**LAT** Pieļieciet pamišus  
**LIT** Užsukinėkite pakaitomis  
**PL** Śruby dokręcaj naprzemiennie  
**RU** Затягивайте попеременно





**CZ** Pokręťta bagażnika dokręcaj dokręcaj naprzemiennie.  
**SK** Dofahajte striedavo  
**SLO** Privijajte izmenično.  
**HR** Naizmjenočno zategnite  
**HU** Egymástól függetlenül szorítandó  
**GR** Σφιγίγτες εναλλάξ  
**TR** Dönüşümlü sıkın

**中文** 交替拧紧



**한국어** 번갈아 가며 조이십시오.

**日本語** 交互に締め付けてください。

**ไทย** ชันในแบบสลับ





≈ 3 Nm





8




x1  
17 mm







**THULE**  
SWEDEN  
**ONE  
KEY  
SYSTEM**




**544** (x4)

**596** (x6)

**588** (x8)

NA **510** (x10)

EUR **452** (x12)  
ASIA



WW ▶ Thule Sweden AB, Box 69, 330 33 Hillerstorp, SWEDEN  
NA ▶ Thule Inc., 42 Silvermine Road, Seymour, Connecticut 06483, USA

info@thule.com  
customer.service@thule.com

www.thule.com

503-1205-02