





Kit 1102

HONDA CR-V, 5-dr SUV, 97-01



480R
754



480



750





x2	x2	x2	x2	x2
x2		x2	x2	
x2		x4		
x4		x4		



Kit







3






	X
HONDA CR-V, 5-dr SUV, 97-01	34,5




	Y
HONDA CR-V, 5-dr SUV, 97-01	32,5



	X inch	X mm
HONDA CR-V, 5-dr SUV, 97-01	39 1/4"	996 mm








	Y inch	Y mm
HONDA CR-V, 5-dr SUV, 97-01	38 3/8"	976 mm



4




HONDA CR-V, 5-dr SUV, 97-01



5



	X mm	Y mm	X inch	Y inch
HONDA CR-V, 5-dr SUV, 97-01	350 mm	700 mm	13 ³ / ₄ "	27 ¹ / ₂ "



GB/US Tighten alternately

D Die Schrauben abwechselnd anziehen

F Serrer alternativement chaque côté

NL Afwisselend aan de linker- en de rechterkant aandraaien

I Alternare il serraggio delle viti

E Serrare alternativamente

PT Aperte alternadamente

S Dra åt växelvis

FIN Kierrä vuorotellen

EST Pinguldage vaheldumisi

LAT Pielieciet pamišus

LIT Užsukinėkite pakaitomis

PL Śruby dokręcaj naprzemiennie

RU Затягивайте попеременно

CZ Pokręťta bagažníka dokręcaj dokręcaj naprzemiennie.

SK Doťahujte striedavo

SLO Privijajte izmenično.

HR Naizmjenično zategnite

HU Egymástól függetlenül szorítandó

GR Σφιγγετε εναλλάξ

TR Dönüşümlü sıkın

中文 交替拧紧

한국어 번갈아 가며 조이십시오.

日本語 交互に締め付けてください。

ไทย ชันในแบบสลับ



6



480R/754




480





*
3 Nm




*





*
≈ 3 Nm




750




4 Nm




i




1




2




i




1




2





i



1



2



THULE
SWEDEN
**ONE
KEY
SYSTEM**



		(x4)
		(x6)
		(x8)
NA		(x10)
EUR		(x12)
ASIA		(x12)



WW ▶ Thule Sweden AB, Box 69, 330 33 Hillerstorp, SWEDEN
NA ▶ Thule Inc., 42 Silvermine Road, Seymour, Connecticut 06483, USA

info@thule.com
customer.service@thule.com

www.thule.com